

# CONNECTING A GRAIN DRYER TO VARI-AIR SYSTEM

**DRY-SET START:** To start air system from a dry-set of contacts from the dryer, close between:

- Terminal #25 - DBCD1
- Terminal #26 - DBCD2

**120V START:** To start air system from 120 Volts coming from the dryer, use terminals:

- Terminal #27 - DBCV1
- Terminal #28 - DBCV2

**AIRLOCK RUN CONFIRM**

- Terminal #29 -ALRC1
- Terminal #30 - ALRC2

**BLOWER RUN CONFIRM**

- Terminal #31 -DS1
- Terminal #32 - DS2

